



DMEGC



INSTALLATION, OPERATION & MAINTENANCE MANUAL OF

DM-INV-TPH4K/5K/6K/8K/10K

H02

V2

www.dmegc-ess.com

I DISCLAIMER

Copyright © Hengdian Group DMEGC Magnetics Co., Ltd. 2024. All rights reserved.
No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Hengdian Group DMEGC Magnetics Co., Ltd.
The material furnished in this document is believed to be accurate and reliable. The information and recommendations in this document do not constitute commitments or warranties in the form of assignments. The information in this document is subject to change without notice. You may refer to the DMEGC Cloud Platform (<https://dmegc.inteless.com>) for the most updated version.
All company and brand products and service names are trademarks or registered trademarks of their respective holders.

I COPYRIGHT STATEMENT

This manual is under the copyright of Hengdian Group DMEGC Magnetics Co., Ltd. with all rights reserved. Please keep the manual properly and operate in strict accordance with all safety and operating instructions in this manual. Please do not operate the product before reading through the manual.

TABLE OF CONTENTS

01	INTRODUCTION	01
1.1	Content and structure of this document	01
1.2	Target group	01
1.3	Levels of warning messages	01
1.4	Definition of abbreviations and nouns	01
02	SAFETY	02
2.1	Intended use	02
2.2	Safety instructions for battery	02
2.2.1	General safety precautions	02
2.2.2	Response to emergency situations	02
2.3	Important safety instructions	03
2.4	Symbols explanation	04
03	PRODUCT INTRODUCTION AND APPLICATION SCENARIOS	06
3.1	Nomenclature introduction	06
3.2	System introduction	06
3.3	Product description	06
3.3.1	Inverter electrical interface introduction	06
3.3.2	Inverter display interface introduction	07
3.3.2.1	Main interface of the inverter LCD	07
3.3.2.2	Display content of sub-menu status item	07
3.3.2.3	Display content of sub-menu history item	09
3.3.2.4	Display content of general setting item	10
3.3.2.5	Display content of parallel setting item	11
3.3.2.6	Set the mode for the inverter to respond to power dispatching	12
3.3.2.7	Overloaded state	14
3.3.2.8	DRM Enable setting method as page	14
3.3.3	Battery introduction	15
3.4	Application scenarios	16
04	STORAGE AND TRANSPORT	17
4.1	Storage	17
4.1.1	Inverter storage	17
4.1.2	Battery storage	18
4.2	Transport	18
05	MOUNTING	18
5.1	Checking the outer packing	18
5.2	Scope of delivery	19
5.2.1	Scope of delivery for inverter installation	19
5.2.2	Scope of delivery for wall bracket installation(optional)	19

5.2.3 Scope of delivery for battery H02 installation	20
5.3 Requirements for mounting	21
5.3.1 Basic requirements	21
5.3.2 Mounting environment requirements	21
5.3.3 Mounting structure requirements	21
5.3.4 Mounting angle and stack requirement	22
5.3.5 Mounting space requirements	22
5.4 Preparing tools and instruments	23
5.5 Mounting the product	24
5.5.1 Mounting the battery	24
5.5.1.1. Mounting the battery H02	24
5.5.2 Mounting the inverter	29

06 ELECTRICAL CONNECTION 30

6.1 Cable requirements for connection	30
6.2 Connecting additional grounding	31
6.3 AC connection	32
6.3.1 Requirements for the AC connection	32
6.3.2 Grid and backup connection	32
6.3.3 Electricity meter connection	34
6.3.4 Configuring the chint meter	36
6.4 PV connection	37
6.5 Electrical connection between the inverter and battery packs	38
6.5.1 Electrical connection between the inverter and battery	38
6.5.2 Electrical connection between batteries	39
6.5.3 PE Connection	40
6.5.4 AUX/LAN/DRM、 RRCR/Meter/RS485/BMS connection	41

07 INSTALLER ACCOUNT REGISTER AND INSTALL NEW SYSTEM 42

7.1 Register on app	42
7.1.1 Download and install app	43
7.1.2 Register as installer account	42
7.1.3 Overview of functions for installer account	43
7.1.4 Install new system	44
7.1.5. Inverter setting	46
7.2. Register on cloud	47
7.2.1 Register as installer account	47
7.2.2 Install new system	47
7.2.3. Power quality response	48

08 POWERING ON AND OFF THE SYSTEM 49

8.1 Powering on the system	49
8.2 Powering off the system	49

09 COMMISSIONING 50

9.1 Checking before power-on	50
------------------------------------	----

9.2 Mount the cover	50
9.2.1 Mount the covers of the inverter (installed on the battery)	50
9.2.1.1. Mount the top cover	50
9.2.1.2. Mount the right cover	51
9.2.1.3. Connect the grid / backup connector and mount the cable cover	51
9.2.2. Mount the inverter with wall bracket (optional)	51
9.2.2.1. Mount the inverter	51
9.2.2.3. Mounting the right cover and cable cover	52
9.3 Mount the Wi-Fi module	52
10 PARALLEL SETUP	53
10.1 Inverters Operation in Parallel Mounting	53
10.2 Scope of Delivery	53
10.3 Electrical Connection	54
10.3.1 AC Wiring to Grid Combiner Cabinet	53
10.3.2 Verify the Electrical Connection	53
10.4 Commissioning	54
10.4.1 System Upgrade	54
10.4.2 Set the parallel function	55
10.5 Power ON and OFF the Three Phase Parallel System	55
11 MAINTENANCE AND TROUBLESHOOTING	55
11.1 Routine maintenance	55
11.2 Troubleshooting	56
11.2.1 Inverter error troubleshooting	56
11.2.2 Battery protection troubleshooting	59
11.2.3 Battery error troubleshooting	60
11.2.4 Earth fault alarm and troubleshooting	61
12 UNINSTALLATION & RETURN	61
12.1 Removing the product	61
12.2 Packing the product	61
12.3 Disposing of the product	61
13 SPECIFICATION	61
13.1 Datasheet of inverter	61
13.2 Datasheet of battery	65
14 CONTACT US	71
15 AUSTRALIAN IMPORTER	71

1.1. CONTENT AND STRUCTURE OF THIS DOCUMENT

This document is valid for:

Inverter: DM-INV-TPH4K, DM-INV-TPH5K, DM-INV-TPH6K, DM-INV-TPH8K, DM-INV-TPH10K

Battery: H02

This document describes the mounting, installation, commissioning, configuration, operation of the product as well as the operation of the product user interface.

Read this document through, understand the safety information, and get familiar with the functions and features of the device before installing and operating it.

Illustrations in this document are reduced to the essential information and may deviate from the real product.

You will find the latest version of this document and further information on the product in PDF format at www.dmecg.inteless.com.

1.2. Target group

This document is intended for qualified persons and end users. Only qualified persons are allowed to perform the operations marked with a warning symbol in this document. Tasks that do not require any specific qualifications will not be marked and can be performed by the end user. Qualified persons must have.

- Knowledge of working principle of inverters.
- Knowledge of how to deal with the dangers and risks associated with installing and using electrical devices, batteries and systems.
- Knowledge of the installation and commissioning of electrical devices and systems.
- Knowledge of the applicable standards and directives.
- Understood and complied with this document, including all safety precautions.
- Understood and complied with the documents of the battery manufacturer, including all safety precautions.

1.3. Levels of warning messages

The following levels of warning messages may occur when handling the product

Symbol	Description
 DANGER	DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.
 WARNING	WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION	CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE	NOTICE indicates a situation which, if not avoided, can result in property damage.
INFORMATION provides tips which are valuable for the optimal installation and operation of the product.	

1.4. Definition of abbreviations and nouns

AC	alternating current	AUX	auxiliary
APP	application	EMS	energy management system

BAT	battery	INV	inverter
BMS	battery management system	MPPT	maximum power point tracking
DC	direct current	PV	photovoltaic

02 SAFETY

2.1. Intended use

The inverter, battery packs and the electricity meters make up a system for optimization of self-consumption for a household. The inverter can achieve bidirectional transfer between AC current and DC current. The battery pack is used for the energy storage.

This system is suitable for indoor and outdoor installation.

Inverter must only be operated with PV arrays of protection class II in accordance with IEC 61730, application class A. The PV modules must be compatible with this product.

PV modules with a high capacity to ground must only be used if their coupling capacity does not exceed 1.0 μ F.

All components must operate in a scenario suitable for their operation.

Be sure to use this product in accordance with the information provided in the accompanying documents and local applicable standards and directives. Any other operation may cause personal injury or property damage.

Alterations to the product, e.g. changes or modifications, are only permitted with the express written permission of DMEGC. Unauthorized alterations will void guarantee and warranty claims. DMEGC shall not be held liable for any damage caused by such changes.

Any use of the product other than that described in the Intended Use section does not qualify as appropriate.

The enclosed documentation is an integral part of this product. Keep the documentation in a convenient place for future reference and comply with all instructions contained therein.

The type label must remain permanently attached to the product.

2.2. Safety instructions for battery

2.2.1. General safety precautions

- Over voltage or wrong wiring can damage the battery pack and cause deflagration, which can be extremely dangerous.
- All types of breakdown of the battery may lead to a leakage of electrolyte or flammable gas.
- Battery pack is not user-serviceable. There is high voltage in the device.
- Read the label with Warning Symbols and Precautions, which is on the right side of the battery pack.
- Do not connect any AC conductors or PV conductors directly to the battery pack which should be only connected to the inverter.
- Do not charge or discharge damaged battery.
- Do not damage the battery pack in such ways as dropping, deforming, impacting, cutting or penetrating with a sharp object. It may cause a leakage of electrolyte or fire.
- Do not expose battery to open flame.

2.2.2. Response to emergency situations

The battery pack is composed of multiple batteries and designed to prevent the danger caused by malfunction.

If the user touches the inner material of the battery cells due to damage to the shell, the following actions are recommended.

1. Inhalation: Leave the contaminated area immediately and seek medical attention.
2. Eye injuries: Rinse eyes with running water for 15 minutes and seek medical attention.
3. Skin injuries: Wash the contacted area with soap thoroughly and seek medical attention.
4. Ingestion: Induce vomiting and seek medical attention.

If a fire breaks out in the place where the battery pack is installed, perform the following counter-measures:

- **Fire extinguishing media**

1. Respirator is not required during normal operations.
2. Use FM-200 or CO₂ extinguisher for battery fire.
3. Use an ABC fire extinguisher, if the fire is not from battery and not spread to it yet.

- **Firefighting instructions**

1. If fire occurs when charging batteries, if it is safe to do so, disconnect the battery pack circuit breaker to shut off the power to charge.
2. If the battery pack is not on fire yet, extinguish the fire before the battery pack catches fire.
3. If the battery pack is on fire, do not try to extinguish but evacuate people immediately.

⚠ WARNING

There may be a possible explosion when batteries are heated above 150°C. When the battery pack is burning, it leaks poisonous gases. Do not approach.

- **Effective ways to deal with accidents**

1. On land: Place damaged battery into a segregated place and call local fire department or service engineer.
2. In water: Stay out of the water and don't touch anything if any part of the battery, inverter, or wiring is submerged.
3. Do not use submerged battery again and contact the service engineer.

2.3. Important safety instructions

⚠ DANGER

Danger to life due to electric shock when live components or cables are touched.

There is high voltage in the conductive components or cables of the product. Touching live parts and cables can result in death or lethal injuries due to electric shock.

- Do not touch non-insulated parts or cables.
- Disconnect the product from voltage sources and make sure it cannot be reconnected before working on the inverter or the battery pack.
- After disconnection, wait for 5 minutes until the capacitors have discharged.
- Do not open the product.
- Wear suitable personal protective equipment for all operations on the product.

⚠ DANGER

Danger to life due to danger voltages on the battery pack.

There is danger voltage at the pin connector for the power cable. Reaching into the pin connector for the power cable can result in lethal electric shock.

- Do not open the battery pack.
- Do not wipe over the battery pack with a damp cloth.
- Leave the protective caps on the pin connectors for the batteries power connection until the inverter cables are connected to the battery pack.
- Disconnect the system from voltage sources and make sure it cannot be reconnected before working on the inverter or the battery pack.

⚠ WARNING

Risk of chemical burns from electrolyte or toxic gases.

During normal operation, no electrolyte would leak from the battery pack and no toxic gases would form. Despite careful construction, if the battery pack is damaged or a fault occurs, it is possible that electrolyte may be leaked or toxic gases may form.

- Store the battery pack in a cool and dry place.
- Do not drop the battery pack or damage it with sharp objects.
- Only set the battery pack down on its back or its bottom.

- Do not open the battery pack.
- Do not install or operate the battery pack in potentially explosive atmosphere or areas of high humidity.
- If moisture has penetrated the battery pack (e.g. due to a damaged housing), do not install or operate the battery pack.
- In case of contact with electrolyte, rinse the affected areas immediately with water and consult a doctor without delay.

⚠ CAUTION

Risk of burns due to hot heatsink and housing.

The heatsink and housing can get hot during operation.

During operation, do not touch any parts other than the cover of the inverter.

NOTICE

Damage to the inverter due to electrostatic discharge.

- Touching electronic components can cause damage to or destroy the inverter through electrostatic discharge.
- Ground yourself before touching any component.

NOTICE

Damage due to cleaning agents.

- The use of cleaning agents may cause damage to the product and its components.
- Clean the product and all its components only with a cloth moistened with clear water.

⚠ DANGER

Danger to life due to electric shock when live components or PV cables are touched.

When PV panels exposed to sunlight, the PV array generates high DC voltage which presents in the DC conductors. Touching the live DC cables can result in death or lethal injuries due to electric shock.

- Disconnect the inverter from voltage sources and make sure it cannot be reconnected before working on the device.
- Do not touch non-insulated parts or cables.
- Do not disconnect the DC connectors under load.
- Wear suitable personal protective equipment for all work on the inverter.

⚠ DANGER

Danger to life due to electric shock from touching an ungrounded PV module or array frame.

- Touching ungrounded PV modules or array frames can result in death or lethal injuries due to electric shock.
- Connect and ground the frame of the PV modules, the array frame and the electrically conductive surfaces so that there is continuous conduction.
- Observe the applicable local regulations.

⚠ DANGER

Danger to life due to electric shock when touching live system components in case of a ground fault.

When a ground fault occurs, parts of the system may still be live. Touching live parts and cables can result in death or lethal injuries due to electric shock.

- Disconnect the product from voltage sources and make sure it cannot be reconnected before working on the device.
- Touch the cables of the PV array on the insulation only.
- Do not touch any parts of the substructure or frame of the PV array.
- Do not connect PV strings with ground faults to the inverter.

2.4. Symbols explanation

Symbol	Explanation
	Beware of a danger zone This symbol indicates that the product must be additionally grounded if additional grounding or equipotential bonding is required at the installation site.
	Beware of electrical voltage The product operates at high voltages.



Beware of hot surface
The product can get hot during operation.



Danger to life due to high voltages in the inverter, observe a waiting time of 5 minutes. Prior to performing any work on the inverter, dis-connect it from all voltage sources as described in this document.



WEEE designation
Do not dispose of the product together with the household waste but in accordance with the disposal regulations for electronic waste applicable at the installation site.



Observe the documentation.



CE marking
The product complies with the requirements of the applicable EU directives.



Certified safety
The product is TUV-tested and complies with the requirements of the EU Equipment and Product Safety Act.



RCM (Regulatory Compliance Mark)
The product complies with the requirements of the applicable Australian standards.



UKCA marking
The product complies with the regulations of the applicable laws of England, Wales and Scotland.



RoHS labeling
The product complies with the requirements of the applicable EU directives.



Risk of chemical burns.



Risk of explosion.



Risk of electrolyte leakage.



Refer to the instruction for operation.



Use eye protection.



Fire, naked light and smoking prohibited.



No nearing.



Do not dispose of the battery pack together with the household waste but in accordance with the locally applicable disposal regulations for batteries.



Recycling code.

UN38.3

Marking for transport of dangerous goods
The product passes the certifications of the UN38.3.

03 PRODUCT INTRODUCTION AND APPLICATION SCENARIOS

3.1. Nomenclature introduction

Name	Designation in this document
DM-INV-TPH4K	4kW Three-Phase Hybrid Inverter
DM-INV-TPH5K	5kW Three-Phase Hybrid Inverter
DM-INV-TPH6K	6kW Three-Phase Hybrid Inverter
DM-INV-TPH8K	8kW Three-Phase Hybrid Inverter
DM-INV-TPH10K	10kW Three-Phase Hybrid Inverter
H02	Battery

3.2. System introduction



DMEGC HOME BESS

Dimension(W×H×D):


590×(416+181+333*N+78)×204mm

N: Number of batteries

Object	Name	Explain
1	DM-INV-TPH4K DM-INV-TPH5K DM-INV-TPH6K DM-INV-TPH8K DM-INV-TPH10K	Inverter
2	H02	Battery

3.3. Product description

3.3.1. Inverter electrical interface introduction



Position	Designation
1	Backup Connector
2	Grid Connector
3	Grounding Point
4	PV Switch
5	PV Connectors
6	BAT Connectors
7	Battery Circuit Breaker*
8	Communication Ports(CAN/RS485,BMS, LAN, METER, DRM**, AUX)
9	Wi-Fi Port
10	LCD Display

*All breakers of the product are switched off when shipped.

**The DRM is only for regions with AS/NZS 4777.2 safety regulations.

3.3.2. Inverter display interface introduction

Object	Name	Description	
A	SYS LED	Red: The inverter is in fault.	
		White: The inverter is in normal state.	
	BAT LED	White: The battery is in charging or discharging.	
	COM LED	White: The inverter is in communication.	
B	LCD Dispaly	Display the information of the energy storage system.	
C	Button Function		Escape from current interface or function.
			Move cursor to upside or increase value.
			Move cursor to downside or decrease value.
			Confirm the selection.

3.3.2.1 Main interface of the inverter LCD

<table border="1"> <tr> <td>Power</td><td>0W</td></tr> <tr> <td>Total</td><td>00.0kWh</td></tr> <tr> <td>Battery</td><td>%</td></tr> <tr> <td colspan="2">Normal</td></tr> </table>	Power	0W	Total	00.0kWh	Battery	%	Normal		<p>Main displays the inverter working status and information, including:</p> <ol style="list-style-type: none"> 1.Power: Current PV power. 2.Total: Total power generation. 3.Battery: Current remaining battery power (SOC). 4.Normal: Current working state of the equipment, including Standby. 				
Power	0W												
Total	00.0kWh												
Battery	%												
Normal													
<table border="1"> <tr> <td>>>></td><td>MENU</td><td><<<</td></tr> <tr> <td colspan="3">>Status</td></tr> <tr> <td colspan="3">History</td></tr> <tr> <td colspan="3">Setting</td></tr> </table>	>>>	MENU	<<<	>Status			History			Setting			<p>In the Main interface, press ENT key to enter the menu's main interface. Use the up and down key to select a sub-menu, press the ENT key to enter the selected sub-menu, press Return key to return to the previous layer.</p>
>>>	MENU	<<<											
>Status													
History													
Setting													

3.3.2.2 Display content of sub-menu status item

<table border="1"> <tr> <td>>>></td><td>Status</td><td><<<</td></tr> <tr> <td colspan="3">>Grid</td></tr> <tr> <td colspan="3">Soalr</td></tr> <tr> <td colspan="3">Battery</td></tr> </table>	>>>	Status	<<<	>Grid			Soalr			Battery			<p>Status menu contains five sub-menus: Solar, Battery, Grid, UPS and Comm. These display the relevant information about the current physical or communication interface respectively.</p>
>>>	Status	<<<											
>Grid													
Soalr													
Battery													

<pre>>>> Grid <<< >U1 230.2V I1 2.0A F1 49.99Hz</pre>	<p>Grid interface displays the real-time information on the utility grid side: voltage U1, current I1, frequency F1, PInv, PMeter AC, PMeter DC.</p>
<pre>>>> Grid <<< >U2 230.2V I2 2.0A F2 49.99Hz</pre>	<p>Grid interface displays the real-time information on the utility grid side: voltage U2, current I2, frequency F2, PInv, PMeter AC, PMeter DC.</p>
<pre>>>> Grid <<< >U3 230.2V I3 2.0A F3 49.99Hz</pre>	<p>Grid interface displays the real-time information on the utility grid side: voltage U3, current I3, frequency F3, PInv, PMeter AC, PMeter DC.</p>
<pre>>>> Solar <<< >U1 360.0V I1 1.0A P1 360W</pre>	<p>Solar interface displays the real-time information of PV side: voltage U1, current I1, power P1.</p>
<pre>>>> Solar <<< >U2 360.0V I2 1.0A P2 360W</pre>	<p>Solar interface displays the real-time information of PV side: voltage U2, current I2 and power P2.</p>
<pre>>>> Solar <<< >U3 360.0V I3 1.0A P3 360W</pre>	<p>Solar interface displays the real-time information of PV side: voltage U3, current I3 and power P3.</p>
<pre>>>> Battery <<< >U 96.0V I 10.0A P 960W</pre>	<p>Battery interface displays the real-time information of battery side: voltage U, current I, power P, residual capacity of Battery (SOC), the internal environmental temperature Temp.</p>
<pre>>>> UPS <<< >U1 230.2V I1 2.0A P1 460W</pre>	<p>UPS interface displays the real-time information in this mode: voltage U1, current I1, power P1, frequency F.</p>
<pre>>>> UPS <<< >U2 230.2V I2 2.0A P2 460W</pre>	<p>UPS interface displays the real-time information in this mode: voltage U2, current I2, power P2, frequency F.</p>
<pre>>>> UPS <<< >U3 230.2V I3 2.0A P3 460W</pre>	<p>UPS interface displays the real-time information in this mode: voltage U3, current I3, power P3, frequency F.</p>

>>> Comm <<< >BMS Yes Net Yes MeterGrid Yes	Communication interface displays the real-time communication situation of BMS, Net, MeterGrid and MeterDC.
--	--

3.3.2.3 Display content of sub-menu history item

>>> History <<< >Grid Consump INV Gen. BAT Gen.	History menu contains seven sub-menus: Grid Consumption, INV Gen., BAT Gen., PV Gen., Grid Charge., PV Charge., Error Logs.
> Grid CONSUMP < > Total: 0.0kWh	Grid Consumption interface displays today's or total load consumption from grid.
>>> INV Gen. <<< >Today: 29.1kWh	INV Gen. interface displays today's or total electricity quantity generated from Inverter.
>>> Bat Gen. <<< >Today: 13.8kWh	Bat Gen. interface displays today's or total electricity quantity discharged from the battery.
>>> PV Gen. <<< >Today: 19.0kWh	PV Gen. interface displays today's or total electricity quantity generated from the PV-panels.
>>> Grid Charge <<< >Today: 1.9kWh	Grid Charge interface displays today's or total electricity quantity battery charging from the grid.
>>> PV Charge <<< >Today: 13.1kWh	PV Charge interface displays today's or total electricity quantity battery charging from the PV-panels.
>>> Error Logs <<< 1: 2018-02-02 16:48 Chg SPI Fault	Error Logs interface displays the 10 latest fault records of this device, including the name of the fault and time of error.
>> Information < >SN: XXXXXXXXXXXXXXXX	Make sure all numbers in the information menu are correct.

>> Information < >Inverter Ver.:	Check the inverter software version.
-------------------------------------	--------------------------------------

3.3.2.4 Display content of general setting item

> New Password < > 0 0 0 0	<p>Step1: Click setting and enter the password. Please call customer service to obtain the password, the installation's password is a four-digits password, after four-digits password was correctly input, you can enter into the main Setting interface (administrator permission).</p>	
>>> Setting <<< >Function Safety	>>> Function <<< >Solar Battery Grid	>>> Solar <<< >On Grid Cap. 000000W
<p>Step2: Click Function to enter function setting.</p>	<p>Step3: Click Solar to set the Solar relevant information.</p>	<p>Step4: Set on-grid capacity, storage capacity and number of PV strings (MPPT number).</p>
>>>> Battery <<<< >Bat Model DM-BAT-XXX	>>>> Battery <<<< >SOC Calibration No	>>>> Battery <<<< >Battery Ready No
<p>Step5: Click the Battery Function and check battery type.</p>	<p>Step6: Check SOC Calibration function set No.</p>	<p>Step7: Check the Battery Ready function set No. If you only use the inverter without battery, please set it Yes.</p>
>>>> Grid <<<< >FeedIN Control Power Limit Power Factor	Max. Feed in rate >User Value 50%	>> System Mode << >DC AC Hybrid
<p>Step8: Click the Grid Function to set up relevant parameters of the grid.</p>	<p>Step9: Set the Max. Feed-in power rate value. If you do not want to send power to the grid, set it to 0%.</p>	<p>Step10: Click Function-System Mode to set system mode: DC, AC, Hybrid.</p>
>>> Work Mode << >Force Charge Enable	>>> Work Mode << >Force Charge Enable	>>> Work Mode << > Charge Start Time 1 01:00
<p>Step11: Click the mode then set up work mode.(self-use or force time charge)</p>	<p>Step12: If you want to use force charge, set Enable here.</p>	<p>Step13: Set the charge and discharge time.</p>

<pre>>>> Work Mode <<< >UPS Reserve SOC 11%</pre> <p>Step14: Set the UPS Reserve SOC, it means how much battery energy to reserve for UPS function.</p>	<pre>>>>> Safety <<<< > Country AS4777.2-A</pre> <p>Step15: Click Safety in the setting menu. Set safety standard. For example: AS4777.2-A/AS4777.2-B/AS4777.2-C for Australia, VDE4105 for Germany, CEI0_21 for Italy, G83_2 for Great Britain, NRS097_2_1 for South Africa, RD1699 for Spain, VDE0216 for 60Hz countries.</p>
<pre>>>> CT Meter <<< >Enable OFF Ratio 1</pre> <p>Step16: If you use CT meter, please set CT meter enable and the relevant ratio.</p>	<pre>>> Date&Time << > 2018-02-02 09:46</pre> <p>Step17: Click System in the setting menu. Click Date &Time and set up the date and time.</p>
<pre>>>> Ethernet <<< IP method > DHCP</pre>	<p>Step18: Click Ethernet to set the IP address. DHCP mode means that setup IP address is set up automatically. If you want to set up the IP address manually, please choose manual mode.</p>
<p>Note: It is needed to set the following 3 parameters for manual mode: IP Address: IP address; Subnet Mask: Subnet mask; Default Gateway: Default gateway; Automatic display one parameter: MAC Address: display MAC Address.</p>	
<pre>>>>> Language <<<< > English Deutsch Italian</pre> <p>Step19: Click Language to set Language Date & Time Setting Interface.</p>	<pre>>>> Information <<< >SN: XXXXXXXXXXXXXX</pre> <p>Step20: Make sure all the following number is correct. Date & Time Setting Interface.</p>

3.3.2.5 Display content of parallel setting item

<pre>>>> Function <<< >Parallel Grid Forming Generator</pre>	<p>Step1: Click Parallel to enter parallel setting.</p>
---	--

<pre>>> Parallel << AC Parallel DC Parallel >Parallel Grid</pre>	<p>Step2: Click Parallel Grid to set the Parallel Grid relevant information.</p>
<p>Step3:</p>	<p>(1): Click the Single to set the inverter to run on a single machine.</p>
	<p>(2): Click the Host to set the Host inverter.</p>
	<p>(3): Click the Follow to set the Follow inverter.</p>

3.3.2.6 Set the mode for the inverter to respond to power dispatching

<pre>>> Inverter power quality response << >modes > Volt-var response mode Volt-watt response mode Fixed power factor Reactive power mode Power rate limit</pre>	<p>Step1: If you use Inverter power quality response, please click Inverter power quality response modes.</p>
<pre>>> Volt-watt response mode << > Values Vv1 Vv2 Vv3 Vv4 Voltage: 207V 220V 240V 258V Q% : 44 0 0 -60 Default setting:Enable</pre>	<p>Step2: Click Volt-var response mode to set the Volt-var response parameter.</p>
<pre>>> Volt-var response mode << > Values Vw1-ch Vw2-ch Vw1 Vw2 Voltage: 207V 215V 253V 260V P% : 20 100 100 20 Default setting:Enable</pre>	<p>Step3: Click Volt-watt response mode to set the Values parameter.</p>

>> Fixed power factor <<
> PF

1.00

Default setting:Enable

Step1: Click Fixed power factor to set the PF parameter.

>> Reactive power mode <<
> Q

0 var

Default setting:Disable

Step2: Click Reactive power mode to set the reactive power.

>> Power rate limit <<
> Wgra

100 %

Default setting:Enable

Step3: Click Power rate limit to set the power rate parameter.

>> Grid Protection settings <<
> Protective function

>Under and over voltage protection
Under and over frequency protection

Step1: If you use Grid Protection, please click Grid Protection settings.

>> Under and over voltage protection <<

> Values

	Voltage	Time
Under voltage 2 (V<<)	70V	2.00s
Under voltage 1 (V<)	180V	11.00s
Over voltage 1 (V>)	265V	2.00s
Over voltage 2 (V>>)	275V	0.20s

Step2: Click Under and over voltage protection to set the parameter.


>> Under and over frequency protection <<

> Values

	Frequency	Time
Under frequency 1(F<)	47 Hz	2.00s
Over frequency1(F>)	52 Hz	0.20s


Step3: Click Under and over frequency protection to set the frequency parameter.

3.3.2.7 Overloaded state



When overloaded, the display show "over load" and scrolls to prompt the customer to reduce some electrical appliances like this "Please turn off some electrical appliances and press the exit button to resume".

3.3.2.8 DRM Enable setting method as page




The DRM function bellowing:


Item	Shorted pin		Description
DRM 0	Pin 5	Pin 6	The inverter the state of "Turn off" and disconnect from the grid.
DRM 1	Pin 1	Pin 6	The absorbed power from the grid is 0% of the rated power.
DRM 2	Pin 2	Pin 6	The absorbed power from the grid is no more than 50% of the rated power.
DRM 3	Pin 3	Pin 6	The absorbed power from the grid is no more than 75% of the rated power.
DRM 4	Pin 4	Pin 6	The absorbed power from the grid is 100% of the rated power.
DRM 5	Pin 1	Pin 51	The feed-in power to the grid is 0% of the rated power.
DRM 6	Pin 2	Pin 5	The feed-in power to the grid is no more than 50% of the rated power.
DRM 7	Pin 3	Pin 5	The feed-in power to the grid is no more than 75% of the rated power.
DRM 8	Pin 4	Pin 5	The feed-in power to the grid is 100% of the rated power.

3.3.3. Battery introduction

Battery pack appearance and dimensions of H02



Connection area overview of H02



Position	Designation
A	The hot-plug interface is connected to the battery module.
B	ON/OFF BUTTON: Start system.
C	BAT SWITCH: A switch for battery's input and output.
D	Bat+: Connect BMS's Bat+ to the inverter's BAT+.
E	Bat-: Connect BMS's Bat- to the inverter's BAT-.
F	CAN: Connect the inverter to BMS's communication.
G	RS485: Only for internal maintenance use.
H	DC switch locking screw hole.

Note: This product is equipped with a self-locking power switch, rotate the battery switch to off, push and then install the lock during decommissioning or maintenance. The self-locking function prevents accidental restart and ensures safe operation.

The four LED indicators on the side cover provide information about the SOC operational status of this battery with lights displaying solid white or flashing.

◆ : White LEDs flash



◆ : White LEDs on

○ : White LEDs off

LED Indicator	No.	SOC	Description
LEDs show the SOC status	1	◆ ○ ○ ○	0% ≤ SOC < 25%
	2	◆ ◆ ○ ○	SOC < 50%
	3	◆ ◆ ◆ ○	SOC < 75%
	4	◆ ◆ ◆ ◆	SOC < 100%
	5	◆ ◆ ◆ ◆	SOC ≥ 100%


3.4. Application scenarios

Storage System (includes inverter DM-INV-TPH4K/DM-INV-TPH5K/DM-INV-TPH6K/DM-INV-TPH8K/DM-INV-TPH10K and battery H02) can be applied in DC-coupled systems (mostly new installation), AC-coupled systems (mostly retrofit), Hybrid-coupled systems (mostly retrofit, and increase the PV capacity), and Off-grid (with Generator) systems as the following schemes show:



Hybrid-coupled Storage System


— Indicates a power cable
- - - - - Indicates a signal cable



Hybrid-coupled Storage System – Scheme

Off grid Storage System


— Indicates a power cable
- - - - - Indicates a signal cable



Off-grid (with Generator) Storage System – Scheme

Off grid Storage System with Dual power switch box

— Indicates a power cable
- - - - - Indicates a signal cable



Off grid (with Dual power switch box)Storage System – Scheme

04 STORAGE AND TRANSPORT

4.1. Storage

4.1.1. Inverter storage

The following requirements should be met if the inverter is not put into use directly:

1. Do not unpack the inverter.
2. Keep the storage temperature at -40~60°C and the humidity at 5%~95% RH.

3. The inverter should be stored in a clean and dry place and be protected from dust and water vapor corrosion.
4. A maximum of six inverters can be stacked. To avoid personal injury or device damage, stack inverters with caution to prevent them from falling over.
5. During the storage period, check the inverter periodically. Replace the packing materials which are damaged by insects or rodents in a timely manner.
6. If the inverters have been stored for more than two years, it must be checked and tested by professionals before being put into use.

4.1.2. Battery storage

The following requirements should be met if the battery is not put into use directly:

1. Place batteries according to the signs on the packing case during storage. Do not put batteries upside down or sidelong.
2. Stack battery packing cases by complying with the stacking requirements on the external package.
3. Store the battery pack out of reach of children and animals.
4. Store the battery pack where it should be minimal dust and dirt in the area.
5. Handle batteries with caution to avoid damage.
6. The storage environment requirements are as follows:
 - a. Ambient temperature: -10~55°C, recommended storage temperature: 15~30°C.
 - b. Relative humidity: 15%~ 85%.
 - c. Place batteries in a dry and clean place with proper ventilation.
 - d. Place batteries in a place that is away from corrosive organic solvents and gases.
 - e. Keep batteries away from direct sunlight.
 - f. Keep batteries at least 2m away from heat sources.
7. The batteries in storage must be disconnected from external devices. The indicators (if any) on the batteries should be off.
8. Batteries should be delivered based on the "first in, first out" rule.
9. The warehouse keeper should collect battery storage information every month and periodically report the battery inventory information to the planning department. The batteries that have been stored for nearly 6 months should be recharged timely.
10. If a lithium battery is stored for a long time, capacity loss may occur. After a lithium battery is stored for 12 months in the recommended storage temperature, the irreversible capacity loss rate is 3%~10%. It is recommended that batteries not be stored for a long period. If the batteries need to be stored for more than 6 months, it is recommended to recharge the batteries to 65~75% of the SOC.

4.2. Transport

During transportation, please follow these guidelines:

1. Priority to use the original packaging for transportation. If the original packaging is not available, put the product inside a suitable cardboard box and seal it properly.
2. Handle with care, choose the corresponding handling method according to the weight, and pay attention to safety.
3. During transportation, please keep the packaging away from dangerous sources and take water-proof measures.
4. Please fix the packaging during transportation to prevent falling or mechanical impact.

05 MOUNTING

















5.1. Checking the outer packing

Before unpacking the product, check the outer packing for damage, such as holes and cracks. If any damage is found, do not unpack the product and contact your dealer as soon as possible.





5.2. Scope of delivery














Check the scope of delivery for completeness and any externally visible damage. Contact your distributor if the scope of delivery is incomplete or damaged.

5.2.1. Scope of delivery for inverter installation




Inverter				
				
Inverter (X1)	TOP Cover (X1)	Right Cover (X1)	Cable Cover (X1)	Left Support Foot (X1)
				
Right Support Foot (X1)	PV+ & PV- Connectors (X3)	Grid Connector(X1)	Backup Connector(X1)	Small Spirit Level (X1)
	 6Pin AUX Terminal (x1) Terminals(x7)		 OT Terminal (x5) M5 Screws (x9)	
WiFi Module (X1)	6 Pin AUX Terminal Block (X2)	RJ45 Plugs (X2)	Screws and Terminals Set (X1)	Wrench Tool (X1)
			 Battery Power-Cable(x1) Battery Power + Cable (x1) Grounding Cable (x1) Communication cable (x1)	
Commissioning Guide & Report (X1)	Quick Installation Guide (X1)	System Wiring Diagram sheets (X1)	INV to BATAccessories Bag	

5.2.2. Scope of delivery for wall bracket installation(optional)

Inverter				
				
Inverter (X1)	TOP Cover (X1)	Right Cover (X1)	Cable Cover (X1)	Horizontal Beams of Wall Bracket (X1)


				
Support Plate for Cable Cover (X1)	Wall Anchor (X1)	Support Stud for Right Cover (X1)	Grid Connector (X1)	Backup Connector (X1)
				
PV Connectors (X3)	Wrench Tool (X1)	WiFi Module (X1)	6 Pin AUX Terminal Block (X2)	Screws and Terminals Set (X1)
				
Small Spirit Level (X1)	Commissioning Guide & Report (X1)	Quick Installation Guide (X1)	System Wiring Diagram sheets (X1)	

5.2.3. Scope of delivery for battery H02 installation

MASTER (H02-MASTER)				
				
Master	Base	Inverter fixed bracket	Expansion screw	M4*12 Phillips head screw
				
M5*12 Phillips head screw	Grounding terminal	Document		

SLAVE Module (H02-SLAVE)				
				
Battery module	Adjustable bracket	M4*12 Phillips head screw	M5*12 Phillips head screw	Expansion screw

Series Box (For ≥2 towers only)

				
Series box	Series base	Adjustable bracket	Expansion screw	M5*12 Phillips head screw
				
Power cable (+)	Power cable (-)	Communication cable	Grounding terminal	Series base terminal cover (x1)
				
Series box terminal cover (x1)				

* Use for mounting right holder for wall bracket and left holder for wall bracket

5.3. Requirements for mounting

WARNING

Danger to life due to fire or explosion

Despite careful construction, electrical devices can cause fires.

- Do not mount the energy storage system in areas containing highly flammable materials or gases.
- Do not mount the energy storage system in potentially explosive atmospheres.

5.3.1. Basic requirements

- The DMEGC Inverter and Battery system is suitable for indoor and outdoor use.
- Do not install the inverter in a place where a person can easily touch it because its housing and heatsink are hot during operation.
- Do not mount the system in areas with flammable or explosive materials.
- Do not mount the inverter at a place within children's reach.
- Do not mount the system outdoors in salt areas because it will be corroded there and may cause fire. A salt area refers to the region within 500m from the coast or prone to sea breeze. The regions prone to sea breeze vary depending on weather conditions (such as typhoons and monsoons) or terrains (such as dams and hills).

5.3.2. Mounting environment requirements

- The system must be mounted in a well-ventilated environment to ensure good heat dissipation.
- When mounted under direct sunlight, the power of the system may be derated due to additional temperature rise.
- Mount the system in a sheltered place or mount an awning over the product.
- The optimal temperature range for the battery pack to operate is from 15 °C to 30 °C.
- Do not expose or place near water sources like downspouts or sprinklers.
- If the battery pack is mounted in the garage, then ensure that it is above the height of the vehicle bumper and/ or door.

5.3.3. Mounting structure requirements


- The mounting structure where the system is mounted must be fireproof.
- Do not mount the system on flammable building materials.
- Ensure that the mounting surface is solid enough to bear the weight load.
- In residential areas, do not mount the inverter on dry walls or walls made of similar materials which have a weak sound insulation performance because the noise generated by the inverter is noticeable.

5.3.4. Mounting angle and stack requirement

The system should be mounted on the wall.

The installation angle requirement is as follow:

- Do not mount the inverter at forward tilted, side tilted, horizontal, or upside down positions.




NOTICE







DM-INV-TPH(4-10)K inverter is only compatible with the H02 battery of DMEGC, independent installation is not supported.

5.3.5. Mounting space requirements

- Reserve sufficient clearance around the product to ensure sufficient space for installation, maintenance and heat dissipation.
- The side clearance is a recommendation. Keep the clearance as short as you can if there is no influence to the operation and maintenance.



5.4. Preparing tools and instruments

Category	Tools and Instruments		
Installation			
	Hammer drill (with a $\Phi 10$ mm drill bit)	Torque socket wrench SW10	Multimeter (DC voltage range ≥ 1000 V DC)
			
	Diagonal pliers	Wire stripper	T20 screwdriver (torque range: 0-5 N m)
			
	Rubber mallet	Utility knife	Cable cutter
			
	Crimping tool (model: PV-CZM-22100)	Cord end terminal crimper	Disassembly and Assembly Tool of PV connector
			
	Vacuum cleaner	Heat shrink tubing	Heat gun
Personal Protective Equipment			
	Marker	Measuring tape	Bubble or digital level
			
Personal Protective Equipment	Safety gloves	Safety goggles	Anti-dust respirator
			
Personal Protective Equipment	Safety shoes	Flat-Head Screwdriver	Socket Wrench

5.5. Mounting the product

5.5.1. Mounting the battery


5.5.1.1. Mounting the battery H02

⚠ NOTICE


The mode of floor mounting is given priority for installation.
Take the installation procedure Option B (With 3 battery modules) as an example.

Step1: Remove the left side cover of the base, then remove and disconnect the power cable.


1



Remove the cover



Unplug the power cable





Remove the power cable

⚠ WARNING

Before installing the base, be sure to remove and disconnect the power cable to avoid accidental electric shock during battery installation.


Step 2: Place a spirit level to check whether the base is even. If yes, refer to the Step 4; if no, refer to the Step 3. The side with "square corner" shall be against the wall, locate the base 20 mm away from the wall.

2




Step 3: Rotate the adjustment screws clockwise to ensure that it is even.

Turn clockwise to lower the base, and turn anticlockwise to raise the base.

3**⚠ NOTICE**

Use a spirit level to measure both side of the base to ensure that the base is even. If not, please rotate the adjustment screws by a hand to ensure that the base is even.

Step 4: Place a slave module on the base. Remove dustproof covers from the slave module before conducting installation.

4**⚠ NOTICE**

The dust cover can only be removed during installation and must be reattached after removing the battery.


Do not touch the terminals during installation or removal of the battery.

At least two persons are required to move the slave module.

Please ensure that the side with "square corner" shall be lean against the wall.


Step 5: Place the second and third slave modules, place the master module, and make sure that the corners and edges of the modules are aligned.

5



Step 6: Install the power cable, then install the left side cover.


6



⚠️ WARNING


Please ensure the battery is powered off before connecting or disconnecting the power cable.

Step 7: Insert and tighten M4×10 screws on both sides(torque: 2.2-2.5 N·m).


7**⚠ NOTICE**

Please make sure that the corners and edges of the base and slave module are aligned before tightening screws.

Step 8: Place the adjustable bracket on the wall, align the hole to the hole on the battery module; and mark the position of the mounting holes. Brackets on both sides of battery modules need to be installed.

8



Step 9: Remove the bracket, and then drill two holes at a depth of more than 60 mm in the concrete wall by using a Drill ($\varnothing 10$ mm).

9

⚠ NOTICE

An electric drill dust collector is recommended.
When drilling holes, make sure the already installed part is covered to prevent dust from falling onto the device.

Step 10: Insert the expansion screws into two holes, tighten the screws to secure the bracket on the wall (torque: 7.5-8 N·m), and then tighten M5×12 screws on both sides (torque: 4.2-4.5 N·m).


10**10****⚠ NOTICE**

If the product is shifted before securing bracket, move it to its original location according to the mark previously drawn.

Step 11: Install the bracket of the top master module, place the bracket on the wall, align the hole to the hole on the master module; and mark the position of the mounting holes.

Remove the bracket, and then drill two holes at a depth of more than 60 mm in the concrete wall by using a Drill ($\varnothing 10$ mm).


Insert the expansion screws into two holes, tighten the screws to secure the bracket on the wall (torque: 7.5-8 N·m), and then tighten M5×12 screws on the top of master module (torque: 4.2-4.5 N·m).



(a) This recommended value is for the location which is the middle hole of the wall bracket for the bottom battery.

For mounting multiple batteries, please follow as above steps.


If you will install extra batteries by side, please keep the distance between two batteries greater than 300mm. You can install extra batteries up to 12 batteries in a system.




5.5.2. Mounting the inverter

- Fit the left and right side brackets onto the top of the battery.
- Attach the inverter to the mounting bracket. Mount the supporting bracket at the bottom of the inverter(M5*12 2.0N.m PH2).


Step 1



Step 2



Step 3



⚠ NOTICE

DM-INV-TPH(4-10)K inverter is only compatible with the H02 battery of DMEGC, independent installation is not supported.

Precautions

DANGER	Before connecting cables, ensure that all breakers of the inverter and the battery packs and all the switches connected to inverters and the battery packs are set to OFF. Otherwise, the danger voltage of the energy storage system may result in electric shocks.
WARNING	<ul style="list-style-type: none"> The energy storage system damage caused by incorrect cable connections is not covered under any warranty. Only certified electricians are allowed to connect cables. <p>Operation personnel must wear proper PPE when connecting cables</p>
NOTICE	<p>The cable colors shown in the electrical connection diagrams provided in this chapter are for reference only.</p> <p>Select cables in accordance with local cable specifications (green-and-yellow cables are only used for PE).</p>

6.1. Cable requirements for connection

No.	Cable	Type	Conductor Cross Section Area Range	Outer Diameter	Source
1	Battery power cable	Standard PV cable in the industry (recommended type: PV1-F)	H02:10mm ²	N/A	Delivered with the battery
2	Battery communication cable	Standard network cable in the industry (recommended type: Cat5e, UTP, UV-resistant for outdoor use)	0.12 ~ 0.2 mm ² (AWG26 ~ AWG24)	N/A	Delivered with the battery
3	PV Power cable	Standard PV cable in the industry (recommended type: PV1-F)	4 ~ 6 mm ²	5.5 ~ 9 mm	Purchased by the installer
4 ^{※1}	Signal cable	Standard network cable in the industry (recommended type: Cat5e, FTP, UV-resistant for outdoor use)	0.12 ~ 0.2 mm ² (AWG26 ~ AWG24)	N/A	Delivered with the inverter
5 ^{※2}	Signal cable	Standard network cable in the industry (recommended type: Cat5e, FTP, UV-resistant for outdoor use)	0.12 ~ 0.2 mm ² (AWG26 ~ AWG24)	4 ~ 6 mm	Purchased by the installer
6 ^{※3}	Signal cable	Multiple-core outdoor shielded twisted pair cable	0.1 ~ 1.3 mm ²	4 ~ 6 mm	Purchased by the installer
7	AC power cable for backup	Three-core (L, N and PE) outdoor copper cable	4 ~ 6 mm ²	13 ~ 17.5 mm	Purchased by the installer

8	AC power cable for grid	Three-core (L, N and PE) outdoor copper cable	4 ~ 6mm ²	13 ~ 17.5 mm	Purchased by the installer
9	PE cable	Single-core outdoor copper cable	6 ~ 10mm ²	N/A	Purchased by the installer

※1 For CT communication connection with inverter.

※2 For CAN/RS485, LAN, Meter, DRM communication connection with inverter.

※3 For AUX communication connection with inverter.

6.2. Connecting additional grounding

NOTICE

Electric Shock Hazard

Before doing electrical connection, please ensure the PV switch & all AC and BAT circuit breakers in the energy storage system are switched OFF and cannot be reactivated.


External grounding points are provided at the left side of the inverter.

Prepare M5 OT terminals, strip the grounding cable insulation, insert the stripped part of the grounding cable into the ring terminal lug and crimp using a crimping tool.


Connect the OT terminal to grounding point using the torque 2.0 N.m with TX20 screwdriver.

Additional grounding connection for inverter.

Step 1: Additional grounding connection




Step 2: Inverter grounding point with battery



Grounding connection between inverter and battery.

Step 3: Grounding connection for series battery



6.3. AC connection

6.3.1. Requirements for the AC connection

NOTICE	Residual-current monitoring unit: If local regulations require the use of a residual-current device, or Hybrid-coupled storage system with big coupling capacity from the PV array and PV inverter, the following must be observed: The inverter is compatible with type B residual-current devices with a rated residual current of 30mA or less. Each inverter in the system must be connected to the utility grid via a separate residual-current device.
⚠ DANGER	You must protect each inverter with an individual grid/backup circuit breaker in order to ensure that the inverter can be disconnected safely.
NOTICE	For Australia and New Zealand installation site, the neutral cable of grid side and backup side must be connected together, otherwise backup output function will not work.

AC connection recommendation for 4kW

Description	Max. Current	Breaker Type for 4kW	Recommend cable cross section
Grid Side	11.6A	16A	2.5~6mm ²
Backup Side	8.7A	16A	2.5~6mm ²

AC connection recommendation for 5kW

Description	Max. Current	Breaker Type for 5kW	Recommend cable cross section
Grid Side	14.5A	25A	4~6mm ²
Backup Side	10.9A	16A	2.5~6mm ²

AC connection recommendation for 6kW

Description	Max. Current	Breaker Type for 6kW	Recommend cable cross section
Grid Side	17.4A	25A	4~6mm ²
Backup Side	13.0A	25A	2.5~6mm ²

AC connection recommendation for 8kW

Description	Max. Current	Breaker Type for 8kW	Recommend cable cross section
Grid Side	23.2A	32A	4~6mm ²
Backup Side	17.4A	25A	4~6mm ²

AC connection recommendation for 10kW

Description	Max. Current	Breaker Type for 10kW	Recommend cable cross section
Grid Side	29A	40A	6mm ²
Backup Side	21.7A	32A	4~6mm ²









Selecting a circuit breaker and copper conductor cross section

You should use APP or Cloud to do the right setting for example when selecting grid circuit breaker specification 32A or 40A and suitable copper conductor cross section, otherwise it increases the danger of the circuit breaker tripping under normal operating conditions.

6.3.2. Grid and backup connection

The steps for connecting the grid connector as follows:





The steps for backup connection are similar as grid connection.



Do not install the grid and backup connector on the inverter.

Disassembly the Grid/Backup Connector




6.3.3. Electricity meter connection

Model	Description	Current	Scenarios
DTSU666	3*230V 5(80)A	65A(a)	Three phase meter (without CT)
DTSU666	3*230V 100A/40mA	100A	Three phase meter (with CT)
DTSU666	3*230V 250A/50mA	250A	Three phase meter (with CT)


(a): Current $\leq 65A$ Per phase

Loosen the swivel nuts of the cable glands on the COM connection cover of Inverter, and unscrew the 4 screws on the corners, then you will see the meter communication ports.




Lead the meter cable through the cable gland of the COM connection cover, don't tighten the swivel nuts of the cable glands.

Insert the RJ45 plugs to the meter communication port.




The other steps for meter (without CT) DTSU666-3*230V 5(80)A connection as follows:

Wiring at Three-phase feed in (DC)




DC-coupled Storage System

Wiring at Three-phase feed in (AC)



AC-coupled Storage System


Wiring at Three-phase feed in (Hybrid)




6.3.4. Configuring the chint meter

Model	Description	Grid Meter Address	PV Meter Address
DTSU666	3*230V 5(80)A (without CT)	1(default)	2

When the meter is used as Grid meter, please follow the steps below to complete the address setting.



When the meter is used as PV meter, please follow the steps below to complete the address setting.



Meter Setting on DMEGC Cloud


Step 1:

If the inverter uses CT to monitor the power on the grid or PV inverter side, click "Grid&PV use CT".
If the inverter only uses Meter to monitor the power on the grid side, click "Grid use Meter PV use CT".

If the inverter uses Meter to monitor the power both on the grid and PV inverter side, click "Grid&PV use Meter".

Step 2:

Click "Save" and wait a few minutes to refresh the page.



Meter Setting on "DMEGC" APP

Step 1:


If the inverter uses CT to monitor the power on the grid or PV inverter side, click "Grid&PV use CT".

If the inverter only uses Meter to monitor the power on the grid side, click "Grid use Meter PV use CT".

If the inverter uses Meter to monitor the power both on the grid and PV inverter side, click "Grid&PV use Meter".

Step 2:

Click "Save", the setting is successful.




6.4. PV connection




Please ensure the follows before connecting PV strings to the Hybrid inverter:

- Make sure the open voltage of the PV strings will not exceed the max. DC input voltage (950-Vdc). Violating this condition will void the warranty.
- Make sure the polarity of the PV connectors is correct.
- Make sure the PV-switch, breakers of battery, AC-BACKUP and AC-Grid are all in their off-states.
- Make sure the PV resistance to ground is higher than 200kOhms.


The inverter uses the Vaconn D4/MC4(optional) PV connectors. Please follow the picture below to assemble the PV connectors.

PV conductor cross section requirements: 4~6 mm².





Disassemble the PV Connectors




6.5. Electrical connection between the inverter and battery packs

6.5.1. Electrical connection between the inverter and battery

Communication cable connection:

- Take out the battery communication cable from the battery package.
- Lead the battery communication cable through the cable gland of the COM connection cover of inverter, don't tighten the swivel nuts of the cable glands, insert the RJ45 plugs to the BMS communication port.
- The battery communication ports of Battery series are on the side of the battery, unscrew the 4 screws of the communication panel and remove it.
- Loosen the swivel nut of the cable gland on the battery communication panel, lead the battery communication cable through the cable gland, insert the RJ45 plugs to the BMS communication port of Battery series.
- Tighten the 4 screws of the communication panel, then tighten swivel nut of the cable gland.



DANGER

Danger to life due to short-circuiting of the battery

Touching the short-circuit connection of the battery results in death or lethal injuries due to electric shock and massive energy release.

- Switch off the battery breaker which is located on the right side of the battery.
- Please connect both ends of one battery power cable completely before connecting the next power cable to avoid short-circuiting of the positive and negative battery power cables.


Power cable connection:

- a. Take out the battery power cables from the battery package.
- b. Remove the protective caps from the battery power connectors.
- c. Connect the battery power cables to the inverter and battery packs.

Please pay attention to the cable polarity, red cable is for battery positive.

NOTE

Before connecting the battery power cables, Replace the connector terminal at one end of the power cable in the attachment with the Amphenol H4P connector.



6.5.2. Electrical connection between batteries

NOTICE


- Connect the cables between the batteries, route them from the rear side of the battery when two batteries mounting side by side.
- In the case of one tower, the base does not need to conduct wiring.
- The wiring procedure for both floor mounting and wall mounting is the same.
- Take the wiring procedure of two towers in floor mounting as an example.

Connect + of the series base to + of the series box;

Connect - of the series base to - of the series box;

Connect CAN port of the series base to CAN port of the series box;

Connect the grounding port of the base to the ground.




6.5.3 PE Connection


The battery must be reliably grounded. The PE connection point has been marked with . It is recommended to connect the battery to a nearby grounding point. For a system with multiple battery towers connected in series, connect the ground points of all battery towers to ensure equipotential connections to ground cables.

PE Connection Procedures


Step 1: Strip the PE cable by wire stripper;




Step 2: Pull the heat-shrink tubing over the PE cable and insert the stripped section into OT terminal;



Step 3: Crimp OT terminal with crimping tool, pull the heat-shrink tubing over the stripped section of the OT terminal and use a heat gun to shrink it so that it can be firmly contacted with the terminal;




Step 4: Connect the PE cable to the battery base of each tower, and secure the M5 nut (Torque: $3.0\pm0.1\text{ N}\cdot\text{m}$).




6.5.4. AUX/LAN/DRM&RRCR/Meter/RS485/BMS connection

For other communication (AUX, LAN, RRCR, DRM, Meter, RS485) connection, please follow the below steps.



1. Loosen the cable glands on the COM connection cover, and then unscrew the 4 screws on the COM connection cover.
2. Lead the communication cables through the cable glands of the COM connection cover, don't tighten the swivel nuts of the cable glands.
Insert the RJ45 plugs to the relative RJ45 sockets.
- 1) For meter wiring, refer to Chapter 6.3.3 for Meter Connection.
- 2) If DRM support is specified, the system may only be used in conjunction with a Demand Response Enabling Device (DRED). This ensures that the system implements the commands from the grid operator for active power limitation at all times. The system and the Demand Response Enabling Device (DRED) must be connected in the same network.
Only DRMO is available for Inverter.

3) Take out 6 pin terminal block for AUX connection. To do wiring connection, insert a screwdriver (blade width: 1.2 mm) into the relative connection position side.
For AUX position definition, please see the AUX wiring documentation.



3. Place the COM connection cover against the inverter housing and tighten the 4 screws, at last secure the swivel nut of the cable glands.

The pin definition of the communication ports:

ITEM	No	1	2	3	4	5	6	7	8
BMS	NC	RS 485-A4	NC	CAN1-H	CAN1-L	NC	RS 485-B4	NC	
RS485	12V	DEBUG-RXD-COM	GND	RS 485-B5	RS 485-A5	NC	DEBUG-TXD-COM	NC	
METER	NC	NC	RS485-A7	NC	NC	RS 485-B7	NC	NC	
DRM	DRED 1/5	DRED 2/6	DRED 3/7	DRED 4/8	REF GEN/0	COM LOAD/0	NC	NC	
RRCR	K1	K2	K3	K4	3.3V	NC			
AUX 1	DO1_NO	DO1_COM	DO1_NC	DI-negative	DI-positive	GND			
AUX 2	DO2_NO	DO2_COM	DO2_NC	DI-negative	DI-positive	GND			

07 INSTALLER ACCOUNT REGISTER AND INSTALL NEW SYSTEM


7.1. Register on app

7.1.1. Download and install app

1. Android device users can download the "DMEGC" App through major Android application markets such as Google Play.
2. IOS device users can search for "DMEGC" in App Store and download the App.







7.1.2. Register as installer account

If you don't have an installer account, please register firstly.



If you already have an installer account, please log in directly.

7.1.3. Overview of functions for installer account




7.1.4. Create plant and Configure network

After logging in to DMEGC you can create your own power station and monitor the power station operating status and power generation data in real time.



1

Click “+” to create a plant




2

Click “Gateway”




3

Scan QR code
of the Wi-Fi Stick




3

Or click “Manual input” to
input the information



4

Enter plant information



5

Click “Distribution network”




6

Click "Wi-Fi Network Configuration"




7

Scan QR code of the Wi-Fi Stick



8

Bluetooth starting "withEAP-" will be automatically connected, click "Connect"



9

Connect to your Wi-Fi with normal internet access, click "Confirm"




10

Configured successfully


NOTICE

1. Prerequisites: Wi-Fi and location services must be enabled in advance. Please ensure that the device is powered on. When the device is powered on, the red LED lights around the device must be on.

7.1.5. Inverter setting



7.1.6. Safety setting



When the safety regulation is set as AS4777 (Australia and New Zealand), the secondary sub options can be selected according to the region or local grid company.

7.2. Register on cloud


7.2.1. Register as installer account

You can create a new account on our web server for the normal monitoring. In addition, a part of our warranty is based on this connection to our web server. The data produced prior to registration can be synchronized to the web server.

Step1: Please use the following steps: Open the portal: dmegc.inteless.com.

Step2: Please fill in "Username", "Password" and click "Log in" if you have already registered.

If not, please register by filling in the following web form:




The screenshot shows a registration form titled "Register". It includes fields for "Please input your phone number/E-mail", "Verification code" (with a "Get code" button), "Please enter password", "Enter the password again", and a "Log in" link for existing users.

In this form, all fields with a red star are compulsory, and you can select the finally users or installation procedures.

***Username:** Must be an email address.


***Password:** 8-20 digits in length, contain numbers and letters, and at least one capital letter, no spaces, Chinese or special symbols. More details are available in the Online Monitoring Web Server Installers User Manual, which can be downloaded from DMEGC homepage.

7.2.2. Create plant




The screenshot shows the "Plant List" section of the DMEGC web interface. It displays a table with columns for Plant Name, Status, Power(kW), E-Today(kWh), and E-Total(kWh). A "Create Plant" button is located in the top right corner.

Log in to your account and choose My Plants > "Create plant" to register new system at DMEGC Cloud.



The screenshot shows the "Create Plant" wizard at step 1, "Add Device". It requires entering the "SN" and "Key" of a gateway. A note says to find the SN and Key on the label of the gateway. Buttons for "Cancel" and "Next" are at the bottom.

Step1: Enter SN and Key of Wi-Fi Stick.



The screenshot shows the "Create Plant" wizard at step 2, "Plant Info.". It requires entering "Plant Name", "Plant Picture" (with a note about file format and size), "Capacity" (with a note about installed capacity), and "Cumulative power generation offset" (with a note about input). Buttons for "Cancel" and "Next" are at the bottom.

Step 2: Enter your plant information.

Create Plant

1 Add Device 2 Plant Info. 3 Revenue Info. 4 Contacts

Currency *

Total Investment ¥

Valuation Method *

Constant Price Time of use price

Please input gains.

Back Next

Step3: Enter Revenue information.

Create Plant

1 Add Device 2 Plant Info. 3 Revenue Info. 4 Contacts

Manager *

Please input Contacts

Phone *

Please enter phone number

E-mail

Please input your E-mail


Back Complete

Enter the gateway S/N, gateway key, Plant information, Revenue information and Contacts, and click the Complete button. The red* in front of it is required.

7.2.3. Power quality response

The quality response function can be adjusted by the DMEGC Cloud system.
Step 1: Select <instruction management>, begin with the instrument setting.

Step 2: Select <Add>, to Determine the number of the instrument and the Management command.



Step 3: Select <dispatch> item for response setting.

Note: designed response mode as following:

- Acitve power - Frequency response.
- Active power - Voltage response.
- Reactive power - Voltage reponse.
- Reactive power - Power response.
- Power factor - Power response.

8 POWERING ON AND OFF THE SYSTEM

8.1. Powering on the system

Procedure

Step1: Switch on the battery breaker which is at the lower left of the inverter.

Step2: Switch on the PV switch (if there is any) on the left side of the inverter.

Step3: Switch on the battery breakers of all batteries.

Step4: Long press the battery power buttons for 3 seconds.

Step5: Switch on the AC breaker between the grid port of the inverter and the grid.

Step6: Switch on the AC breaker between the backup port of the inverter and the loads.

Step7: Switch on the AC breaker (if there is any) between the PV-inverter and the grid.

8.2. Powering off the system

WARNING

After the energy storage system is powered off, the remaining electricity and heat may still cause electric shocks and body burns. Therefore, put on protective gloves and operate the product 5 minutes after the power-off.

Procedure

Step1: Switch off the AC breaker between the Hybrid inverter and the load.

Step2: Switch off the PV switch (if there is any) on the left side of the inverter.

Step3: Switch off the PV switch on the side of the Hybrid inverter if there is any.

Step4: Shortly press the power button.

Step5: Switch off the battery breakers of all batteries.

Step6: Switch off the battery breaker which is at the lower left of the inverter.

Step7: Switch off the AC breaker between the inverter and the grid.


9.1. Checking before power-on

No.	Check Item	Acceptance Criteria
1	Mounting environment	The mounting space is proper, and the mounting environment is clean and tidy, without foreign objects.
2	Battery pack and inverter mounting	The battery pack and inverter are mounted correctly, securely, and reliably.
3	Wi-Fi mounting	The Wi-Fi module is mounted correctly, securely, and reliably.
4	Cable layout	Cables are routed properly as required by the customer.
5	Cable tie	Cable ties are secured evenly and no burr exists.
6	Grounding	The ground cable is connected correctly, securely, and reliably.
7	Switch and breakers status	The PV switch (if there is any) and battery breakers and all the breakers connecting to the product are OFF.
8	Cable connections	The AC cables, PV cables (if there is any), battery power cables, and communication cables are connected correctly, securely, and reliably.
9	Unused power terminals	Unused power ports and communication ports are blocked by watertight caps.


9.2. Mount the cover

9.2.1. Mount the covers of the inverter (installed on the battery)


9.2.1.1. Mount the top cover



9.2.1.2. Mount the right cover





9.2.1.3. Connect the grid & backup connector and mount the cable cover




9.2.2. Mount the inverter with wall bracket (optional)

9.2.2.1. Mount the inverter




9.2.2.3. Mount the right cover and cable cover

Mount the right cover




Mount the cable cover



9.3. Mount the Wi-Fi module.

Remove the Wi-Fi protection cover and screw the Wi-Fi module.



After finishing electrical connection of energy storage system, do the following operations.

- Check the voltage range and frequency range of the grid and the installation of meter (without CT).
- Install the top and right decorative cover of the inverter.
- Follow the instructions in Chapter 8.1. to powering on the system.
- Install the cable cover of the inverter.

10 PARALLEL SETUP


⚠ NOTE

The inverter has not been tested to AS/NZS 4777.2:2020 for multiple inverter combination-sand/or multiple phase inverter combinations, so combinations should not be used (for the products installed in the Australian market).

Inverters Operation in Parallel Mounting

Inverters Operation in Parallel Mounting, the mount steps same as 05 and 9.2

10.2. Scope of Delivery



10.3. Electrical Connection

⚠ ATTENTION

When inverters are operating in parallel, the measurement unit at the feed-in point must utilize the meter type of DTSU666-3*230V 250A/50mA(with CT).

⚠ NOTE

- The batteries connecting to the same inverter must be connected together. The battery cluster connecting the each inverter must not be connected together.
- The number and type of batteries connected to each inverter should be the same.
- The Max. number of series batteries connected to each inverter is 12.
- The backup connection ports of three phase inverter forbid connecting in parallel.
- The grid connection ports (symbolled with "AC") of three phase inverter must be connected in parallel.
- The Max. number of inverters operating in parallel is 3.
- Each inverter operating in parallel must be connected with battery.
- Each inverter operating in parallel must be connected with PV modules.
- Each inverter installing PV modules should have the same PV installed capacity. Otherwise it will cause the battery SOC difference between the battery clusters.

10.3.1. AC Wiring to Grid Combiner Cabinet


Wiring sequence	From	Recommended Cable type	To
1	Mains grid	Five-core (L1, L2, L3, N and PE) outdoor copper cable, 25~35 mm ²	Grid combiner cabinet
2	Grid combiner cabinet	Five-core (L1, L2, L3, N and PE) outdoor copper cable, 4~6 mm ²	Grid connection port of the host inverter
3	Grid combiner cabinet	Five-core (L1, L2, L3, N and PE) outdoor copper cable, 4~6 mm ²	Grid connection port of the follow inverter

10.3.2. Verify the Electrical Connection


Please confirm the following connection

(1) BAT power connection and grounding connection between the batteries connected to each inverter have finished.


- (2) BMS communication connection between the batteries connected to each inverter is completed.
- (3) Please finish PV arrays connection to the inverters, please refer to the “Inverter Quick Installation Guide”(As shown in Figure ①).
- (4) Insert the backup connector plugs into the sockets for the backup connection. When doing so, make sure to align the key on the backup connection socket with the keyway on the backup connector plug (As shown in Figure ②).
- (5) Wiring grid connector plugs, then insert the grid connector plugs into the sockets for the grid connection. When doing so, make sure to align the key on the grid connection socket with the keyway on the grid connector plug (As shown in Figure ③).



- (6) Communicate connection between these inverters, refer to the relative “System Wiring Diagram” of parallel installation.



- (7) Please refer to the “Inverter Quick Installation Guide” to mount the cable cover.



- (8) Contact the technical service team service to upgrade the firmware of the inverters and batteries supporting parallel operation. Switch on the AC circuit breakers between grid connection ports of the inverters and the mains grid and check the LCD of all inverters to see whether the firmware version of the inverters and batteries is consistent with the reminders from service.


10.4. Commissioning

10.4.1. System Upgrade

Contact the technical service team service to upgrade the firmware of the inverters and batteries supporting parallel operation. Switch on the AC circuit breakers between grid connection ports of the inverters and the mains grid and check the LCD of all inverters to see whether the firmware version of the inverters and batteries is consistent with the reminders from service.


10.4.2. Set the parallel function

Inverter display interface introduction



Object	Name	Description	
A	SYS LED	Red: The inverter is in fault. White: The inverter is in normal state.	
	BAT LED	White: The battery is in charging or discharging.	
	COM LED	White: The inverter is in communication.	
B	LCD Dispaly	Display the information of the energy storage system.	
C	Button Function	◀	Escape from current interface or function.
		▲	Move cursor to upside or increase value.
		▼	Move cursor to downside or decrease value.
		○	Confirm the selection.

(1) Installer should execute parallel setting on the LCD of the inverters. Refer to the flow chart below.



(2) After completing the above setup, please confirm whether the system setup is successful and turn off the inverter.

10.5. Power ON and OFF the Three Phase Parallel System

Power on and off the three phase parallel system, the steps same as 08.

11 MAINTENANCE AND TROUBLESHOOTING

11.1. Routine maintenance

Normally, the energy storage system need no maintenance or calibration.

However, in order to maintain the accuracy of the SOC, it is recommended to perform a full charge calibration for SOC (charging battery until the charging power is 0) on the battery at regular intervals (such as two weeks).

Disconnect the system from all power sources before cleaning. Clean the housing, cover and display with a soft cloth.

To ensure that the energy storage system can operate properly in the long term, you are advised to perform routine maintenance on it as described in this chapter.

Maintenance checklist

Check Item	Acceptance Criteria	Maintenance Interval
Product cleanliness	The heatsink at the back of the product are free from obstacles or dust.	Once every 6 to 12 months
Product visible damage	The product are not damaged or deformed.	Once every 6 months
Product running status	1. The product operate with no abnormal sound. 2. All parameters of the product are correctly set. Perform this check when the product is running.	Once every 6 months

Electrical connections	<ol style="list-style-type: none"> 1. Cables are securely connected. 2. Cables are intact, and in particular, the cable jackets touching the metallic surface are not scratched. 3. Unused cable glands are blocked by rubber sealing which are secured by pressure caps. 	Perform the first maintenance 6 months after the initial commissioning. From then on, perform the maintenance once every 6 to 12 months.
------------------------	--	--

⚠ CAUTION

Risk of burns due to hot heatsink and housing

The heatsink and housing of the inverter can get hot during operation.

- During operation, do not touch any parts other than the cover.
- Wait approx. 30 minutes before cleaning until the heatsink has cooled down.

11.2. Troubleshooting

11.2.1. Inverter error troubleshooting

Error No.	Error description	Troubleshooting
100007	Insulation_fault	<ol style="list-style-type: none"> 1. Check whether PV cable connection is reliable. 2. Check whether PV cable is damaged.
100008	GFCI_fault	
100009	Leakage current test failure	Restart system and check whether the fault is existing.
100025	BAT_OVP	Check whether the actual battery voltage exceeds the battery charging cut-off voltage by more than 20V.
100026	BAT_UVP	Check whether the actual battery voltage is lower than the battery discharge cut-off voltage.
100042	Output_short_circuit	<ol style="list-style-type: none"> 1. Use a multimeter to test the impedance of the off grid output. If it is small, check whether the wiring is correct. 2. Restart system, if error still exists, please call the service center.
100043	Output_overload	<ol style="list-style-type: none"> 1. Check whether the load exceeds the rated power. 2. Restart system, if error still exists, please call the service center.
100043	Grid Load Reverse	<ol style="list-style-type: none"> 1. Check whether cables are reversed (whether Grid cable is connected to the Backup side). 2. Restart system, if error still exists, please call the service center.
100144	LPE Reverse	<ol style="list-style-type: none"> 1. Check whether the L cable is connected to the Grounding. 2. Restart system, if error still exists, please call the service center.

100160	DCI	Restart system to see if the fault still exists. If still exists, please call the service center.
100161	SW Consistency	Perform the remote upgrading again and ensure that the version of CPU1 and CPU2 upgrade files is the same.
100162	N-N Reverse Lost	<ol style="list-style-type: none"> 1. The system installed in Australia needs to check whether N-N is short-circuited. 2. If not in Australia, set the safety standard correctly. 3. Restart system, if error still exists, please call the service center.
100220	inv_line_short	<ol style="list-style-type: none"> 1. Check whether the load is short-circuited connected. 2. Restart system, if error still exists, please call the service center.
110000	Bat over-voltage alarm	Check that the actual battery voltage is 10V higher than the battery charging cut off voltage.
110001	Bat under-voltage alarm	Check that the actual battery voltage is 10V higher than the battery discharging cut-off voltage.
110002	output_overload_alarm	Check whether the load exceeds 0.95 of the rated power.
110019	Bat Reverse	Check whether battery positive and negative connections are reversed.
110021	Grid Loss	<ol style="list-style-type: none"> 1. Wait for the Grid power return to normal. 2. If Grid is normal, check the connections to the grid terminal. 3. Restart system, if error still exists, please call the service center.
110022	Grid Volt	
110023	Grid Freq	
110024	10min Grid Volt	
110026	PE Loss	<ol style="list-style-type: none"> 1. Check whether the grounding cable is disconnected. 2. Restart system (This warning does not affect system running).
110027	LN Reverse	<ol style="list-style-type: none"> 1. Check whether the Grid L/N cable are reversed connected. 2. Restart system, if error still exists, please call the service center.

110028	Low Temperature	1. Wait for the temperature to return to normal (above -20 °C). 2. If temperature is normal, restart system, if error still exists, please call the service center.
110029	GFCI	1. Check whether there is leakage current in system cables. 2. If no abnormal connection, but still error frequently, please call the service center.
110033	Island	Normal protection mode, no action is required.
110034	Fan Abnormal	Restart system, if error still exists, please call the service center.
110035	N Loss	1. Check whether the Grid N cable is disconnected. 2. Restart system, if error still exists, please call the service center.
110039	Machine Type	Restart system, if error still exists, please call the service center.
110040	Inv Volt Low	1. Check whether the Backup load power exceeds the inverter rated power. 2. Restart system, if error still exists, please call the service center.
110047	Bus Under	1. Wait for the Grid power restore to normal. 2. Charge the battery and wait until the battery restore.
110051	Reduce PBy Over Freq	Wait for the Grid power restore to normal.
110052	Reduce PBy Over Volt	Wait for the Grid power restore to normal.
110053	Reduce PBy Over Temp	Wait for the inverter temperature returns to normal.
110054	HVRT	Wait for the Grid power restore to normal.
110055	LVRT	Wait for the Grid power restore to normal.
110056	Bat Open	Check the battery circuit breaker and the battery circuit breaker on the inverter are on.
110060	EMS CAN ALARM	Restart system, if error still exists, please call the service center.

110061	EMS SCI ALARM	Restart system, if error still exists, please call the service center.
110074	PV Over Volt	1. Check whether the configured voltage of the PV panel is greater than 950V(Use a multimeter to measure the PV terminal voltage). 2. Restart system, if error still exists, please call the service center.
110082	N-N Reverse Lost	1. The system installed in Australia needs to check whether N-N is short-circuited. 2. If not in Australia, set the safety standard correctly. 3. Restart system, if error still exists, please call the service center.
110083	bat_num_abnormal	Restart system, if error still exists, please call the service center.
34	parallel_host_lost	Host inverter communication lost in parallel system.
35	parallel_form_lost	Slave inverter communication lost in parallel system.
41	parallel_ems_ver_different	Inverter EMS software version mismatch in parallel system.
42	parallel_dsp_ver_different	Inverter DSP software version mismatch in parallel system.
43	parallel_inv_sub_different	Inverter model mismatch in parallel system.

11.2.2. Battery protection troubleshooting

LED Indicator	Error Code	Description	Troubleshooting
Yellow LEDs on or Yellow LEDs flash once per second.	1	Temperature difference	Wait for automatic recovery. If the problem is not be solved yet, please call the service center.
	3	High Temperature	Stop discharging and charging until this code is eliminated and wait for the temperature to drop.
	4	Low-temperature discharge	Stop discharging until this code is eliminated and wait for the temperature to rise.

Yellow LEDs on or Yellow LEDs flash once per second.	5	Over-current charge	Wait for automatic recovery. If the problem is not be solved yet, please call the service center.
	6	Over-current discharge	
	8	Cell overvoltage	
	9	Cell undervoltage	Stop discharging and call the service immediately.
	11	Low-temperature charge	Stop discharging until this code is eliminated and wait for the temperature to rise.

⚠ NOTE	In the case of work mode, if the protection code 9 appears, please press the power button of the battery 5 times within 10 seconds, the BMS will be forced to turn on the MOSFET of discharge so that the inverter can detect the battery open voltage and charge the battery.
---------------	--

11.2.3. Battery error troubleshooting

LED Indicator	Error Code	Description	Troubleshooting
Yellow LEDs on or Yellow LEDs flash once per second.	Error 01	Hardware error	Wait for automatic recovery. If the problem is not be solved yet, please call the service center.
	Error 05	Hardware error	
	Error 06	Circuit breaker open	Switch on circuit breaker after powering off the battery.
	Error 08	LMU disconnect(slave)	Reconnect the BMS communication cable.
	Error 09	SN missing	Call for service.
	Error 10	LMU Disconnect(master)	Reconnect the BMS communication cable.
	Error 11	Software version inconsistent	Call for service.
	Error 12	Multi master	Restart all batteries.
	Error 13	MOS over temperature	Power off the battery and power on the battery after 30minutes.
	Error 14	Insulation fault	Restart battery and in case the problem is not resolved, call for service.
	Error 15	Total voltage fault	Restart battery and in case the problem is not resolved, call for service.

11.2.4. Earth fault alarm and troubleshooting

The earth fault alarm is enabled by default, if an abnormal earth connection occurs, the indicator on the front interface of the inverter will display a red light, and the fault will be sent to the DMEGC App to notify user.

- 1.Check whether the grounding cable is disconnected, or bad connected.
- 2.Restart system (This warning does not affect system running).

12 UNINSTALLATION & RETURN

12.1. Removing the product

Procedure


- Step 1: Power off the energy storage system by following instructions in Chapter 8.2. Powering Off the System.
- Step 2: Disconnect all cables from the product, including communication cables, PV power cables, battery power cables, AC cables, and PE cables.
- Step 3: Remove the WiFi module.
- Step 4: Remove the product from the wall bracket. Remove the expansion battery from the wall bracket.
- Step 5: Remove the wall brackets.

12.2. Packing the product

If the original packaging is available, put the product inside it and then seal it using adhesive tape. If the original packaging is not available, put the product inside a suitable cardboard box and seal it properly.

12.3. Disposing of the product

- If the product service life expires, dispose of it according to the local disposal rules for electrical equipment and electronic component waste.
- Dispose of the packaging and replaced parts according to the rules at the installation site where the device is installed.
- Do not dispose the product with normal domestic waste.



13 SPECIFICATION

13.1. Datasheet of inverter

Item	DM-INV-TPH4K	DM-INV-TPH5K	DM-INV-TPH6K	DM-INV-TPH8K	DM-INV-TPH10K
Input DC (PV side)					
Recommended Max. PV power	8000W	10000W	12000W	16000W	20000W
Max. PV Input Voltage			1100 V		
Rated Voltage			720 V		

Start-up Voltage	85 V				
DVC	DVC-A				
Mppt Voltage Range	140 ~ 950 V				
Max. Input Current Per MPPT	16 A / 16 A / 16 A				
Max. Short Circuit Current Per MPPT	24 A / 24 A / 24 A				
MPPT Number	3				
Max Input Strings Number Per MPPT	1				
Back Feed Current	0A				
Overvoltage Category	II				
Battery					
Battery Type	LFP (LiFePO ₄)				
Battery Voltage Range	90 ~ 700 V				
DVC	DVC-B&C				
Max. Charging Power	4 kW	5 kW	6 kW	8 kW	10 kW
Max. Charge/ Discharge Current	50 A / 50 A				
Communication	CAN				
Overvoltage Category	II				
Back Feed Current	60A				
Output AC (Back-up)					
Rated Output Power	4 kW	5 kW	6 kW	8 kW	10 kW
Max Apparent Output Power	4.4 kVA	5.5 kVA	6.6 kVA	8.8 kVA	11 kVA

Back-up Switch Time	<10 ms				
Rated Output Voltage	3L/N/PE, 380/400V				
Rated Frequency	50/60 Hz				
Rated Output Current	5.8 A	7.2 A	8.7 A	11.6 A	14.5 A
THDV(@linear load)	< 3%				
DVC	DVC-C				
Back Feed Current	37A				
Overvoltage Category	III				
Input AC (Grid side)					
Rated Input Power	8 kW	10 kW	12 kW	16 kW	20 kW
Max. Input Current	11.6 A	14.5 A	17.4 A	23.2 A	29 A
Output AC(Grid side)					
Rated Output Power	4 kW	5 kW	6 kW	8 kW	10 kW
Rated Output Apparent Power	4 kVA	5 kVA	6kVA	8 kVA	10 kVA
Max. Apparent Output Power	4.4 kVA	5.5 kVA	6.6 kVA	8.8 kVA	11 kVA
Operation Phase	Three phase				
Rated Grid Voltage	3L/N/PE, 380/400V				
Grid Voltage Range	150 ~ 288 V				
Rated Grid Frequency	50 / 60 Hz				
Rated Grid Output Current	5.8 A	7.2 A	8.7 A	11.6 A	14.5 A
Power Factor	>0.99 (0.8 leading to 0.8 lagging)				

THDI	< 3%				
Protection Class	I				
Pollution Degree	II				
Overvoltage Category	III				
DVC	DVC-C				
Anti-islanding Protection Method	Frequency shift				
Efficiency					
Max Efficiency	>97.8 %	>97.8 %	>97.8 %	>98 %	>98 %
EU Efficiency	>97.3%	>97.3%	>97.3%	>97.5%	>97.5%
Protection					
Anti-islanding Protection	Integrated				
Insulation Resistor Detection	Integrated				
Residual Current Monitoring Unit	Integrated				
Output Over Current Protection	Integrated				
Output Short Protection	Integrated				
Output Overvoltage Protection	Integrated				
DC Reverse Polarity Protection	Integrated				
PV Overvoltage Protection	Integrated				
PV Switch	Integrated				
Battery Breaker	Integrated				
General Data					

Dimensions (W*H*D)	590*416*205 mm
Weight	29 kg
Topology	Transformerless
Operation Temperature Range	-25 ~ +60 °C
Ingress Protection	IP65
Noise Emission	<30 dB
Cooling Concept	Natural convection
Max. Operation Altitude	3000 m
Grid Connection Standard	G98, VDE-AR-N 4105, EN 50549-1, VDE 0126, RD 1699, CEI 0-21, C10/11, NRS 097-2-1, TOR Erzeuger, MEA, PEA, AS/NZS 4777.2
Safety/ EMC Standard	IEC62109-1/-2 IEC/EN61000-6-1/2/3/4
Features	
PV Connection	Vaconn D4 connectors
Grid Connection	Plug in connector
Back-up Connection	Plug in connector
BAT Connection	Amphenol H4 connectors
Communication	LAN, Wi-Fi
Warranty	120 months

13.2. Datasheet of battery



Model	H02
Battery Type	LFP (LiFePO4)

Weight	52 kg
Dimension (W*D*H)	590 * 333 * 204mm
Ingress Protection	IP65
Energy Capacity	5.12 kWh
Usable Capacity	5.12 kWh
DoD	100%
Rated Voltage	51.2 V
Operating Voltage Range	45.6~ 57.6 V
Rated Charging / Discharging Current *	50 A/50 A
Operating Temperature Range	Charge: 0°C~52°C
	Discharge: -20°C~57°C
Monitoring Parameters	System voltage, current, cell voltage, cell temperature, PCBA temperature
BMS Communication	CAN
System	
Safety	IEC62619/IEC62040
Warranty	120 months
Transportation	UN38.3


* Max. charge/discharge current derating will occur related to temperature and SOC.

Appendix 1: System overview


Please see the following wiring diagram of the system principle, divided into European, Australian and other regions.




1. Three-Phase Inverter System Wiring Diagram with Electricity Meter DTSU666 (Without CT)




2. Three-Phase Inverter System Wiring Diagram with Electricity Meter DTSU666 (With CT)




1.Three-Phase Inverter System Wiring Diagram with Electricity Meter DTSU666 (Without CT)(EU)



2.Three-Phase Inverter System Wiring Diagram with Electricity Meter DTSU666 (With CT)(EU)





Appendix 2: Regional application standard

Please check with your local grid company and choose the correspond Regional Application Standard, the power quality modes Volt-var and Volt-Watt will be running automatically. (Only for regions with AS/NZS 4777.2 safety regulations).

Regional Application Standard	Electric Company	Standarad Code Name
Australia A	N/A	AS4777.2-A
Australia B	N/A	AS4777.2-B
Australia C	N/A	AS4777.2-C
New Zealand	N/A	AS4777.2-New Zealand

14 CONTACT US

Name: Hengdian Group DMEGC Magnetics Co., Ltd.
Address: Hengdian Industrial Zone, Dongyang, Zhejiang, China.
Email: service-ess@dmegc.com.cn
Postcode:322118

15 AUSTRALIAN IMPORTER

DMEGC RENEWABLE ENERGY AUSTRALIA PTY LTD
ABN: 95 671 765 236
Email: xin.wang@dmegc.com.cn
Tel: +61498353593
<https://www.dmegc-ess.com/>
Unit 68 44-50 COOPER ST STRATHFIELD NSW 2111



Hengdian Group DMEGC Magnetics Co., Ltd.

Add.: PV Zone, Xihuan Road, Hengdian, Dongyang City, Zhejiang Province, 310000 P. R. CHINA

Tel.: +86 (0) 571-56260011

E-mail: info-ess@dmegc.com.cn / service-ess@dmegc.com.cn

Copyright © Hengdian Group DMEGC Magnetics Co., Ltd. All rights reserved.